




ASSEMBLE GROMMET AROUND
DRIVE CABLE AND PLUG INTO
DECK HOLE

E3-03814A-01