




- 49C 4046 BL Mod. 11A-T14X668
- 49B 4046 BL Mod. 11A-T14Z668
- 49A GE 46 EP
- 49 HB 48 / SP 45 B



B 45
GOLF JOKER



54 HB 48	54A B 45 / Golf Joker	54B GE 46 EP
54C 4046 BL	54D SP 45 B	

HB 48 55
B 45 / Golf Joker / SP 45 B 55A
GE 46 EP 55B
4046 BL 55C

HB 48 58
B 45 / Golf Joker / SP 45 B 58A
GE 46 EP 58B
4046 BL 58C

56 HB 48 56A B 45 / Golf Joker / 4046 BL 56B GE 46 EP / SP 45 B

57 HB 48
57A B 45 / SP 45 B / Golf Joker
57B GE 46 EP
57C 4046 BL

This diagram shows a golf bag assembly with a handle (50) and a strap (51). It includes a rectangular plate (26) with mounting holes (28, 27) and a cylindrical component (49D). The bag body (49) is shown in a different orientation, with a handle (50) and a strap (51). The diagram also shows a screw (52) and a small rectangular piece (46).