




46 SPE OK

383 SPE


35A (... 5Y667)

35 (... 4Y667)

383 SPE



46 SPE (... 5Y667)
6C TEC-ENGINE



Not shown
nicht abgebildet


6 B&S Engine
6A Hood
6B SCREW

46 SPE (... 4Y667)

6D B&S Engine
6E Hood
6F Screw
6G Prot.Muffler
6H Screw

Mower 383 SPE


not shown
98L



383 SPE

87 (... 4Y667)

87A (... 5Y667)



(... 5Y667) 26A

383 SPE (... 4Y667) 26

(... 5Y667) 28A

(... 4Y667) 28

(383 SPE)

E3-01568 B