





NOTE: 11

4 FLAT WASHERS TO BE USED
WHEN END PLAY IS PRESENT
ON AXLE. USE ONLY 2 FLAT WASHERS
(ONE EACH SIDE AGAINST THE GEAR HUB)
WHEN ASSEMBLY IS TIGHT WITH 4 WASHERS.

E3-08457A-01