


ASSY PULLEY
IN THE INNER HOLE.

USE CABLE TIE TO SECURE
CLEARING DEVICE, MOUNTING CLIP
AND ELECTRIC STARTER CORD TOGETHER
IF EQUIPPED.

SECURE SPRING AND NUT
TO STUD ON BACK OF HOUSING

HOOK ON SPRING MUST
BE AWAY FROM BACK
OF HOUSING



E4-02177A-01